



ALERT AND ALARM SCREENS



ALERTS AND ALARMS WILL BE INDICATED IN THE LOWER RIGHT SECTION OF THE LCD DISPLAY.

ALARM SCREENS

(RED SCREEN)



ALERT SCREENS

(YELLOW SCREEN)

