## HANDLE OPERATION

**OPEN/CLOSE** Press button to unlock handle. Begin rotating and release button, handle will re-lock in open/close position automatically.

