



Flipper Remote

Quick Set Up Guide

Flipper is preset to many TVs and STBs.

To test:

- A. Press and Release TV (light blinks once); test on/off and VOL;
- B. Press and Release STB, test on/off and CH.

If your devices work, then go to 3 below. If not, then:

1. **Set TV:** Press and Hold TV until the light turns solid, then enter the 4 digit code (test on/off and VOL);
2. **Set STB:** Press and Hold STB until the light turns solid, then enter the 4 digit code (test on/off and CH);
3. **Dual Mode:** Press and Release ADD once. Test all keys;
4. **Favorites** (if desired). Go to Manual Booklet, Step 3, page 5.
5. **Lock:** Press and Hold ADD until the light turns solid, then enter 955 (TV only: Press and Hold TV until the light turns solid, then enter 955).

Click for [Device Codes](#), our [Set Up Videos](#), and the [Support Portal](#).

Thank you for your business and we look forward to serving you in the future!

Flipper Remote

Phone: 310-594-7561

Email: support@flipperremote.com

Website: www.flipperremote.com