MAINTENANCE

To ensure safety and proper use, perform the following steps monthly:

- Check all fasteners to ensure that they are securely fastened and no wear and tear is evident. Replace and tighten any worn fasteners before using the Stand Assist.
- Check the two seat assemblies to make sure they are not worn or damaged, and that the bolts are tight. Replace any worn or damaged seat components before using the Stand Assist.
- Check the casters to make sure they are in working order and are secured firmly to the Stand Assist. Replace any worn or damaged casters before using the Stand Assist.

If any maintenance procedure is not clear to you, ask your Graham-Field authorized distributor for assistance.

▲ **NOTICE: Improper maintenance can cause operating problems and may affect your warranty.**

⚠ **WARNING: Unauthorized modification or the use of non-Lumex replacement parts could change the structure of the Stand Assist, void the warranty, and create a hazardous condition resulting in serious personal injury.**

CLEANING THE STAND ASSIST

- Wipe off the frame at least once a week with a soft cloth. Dry the Stand Assist immediately if exposed to moisture.
- Clean the frame every three months with a mild soap and water solution. The frame does not need to be waxed.
- Clean upholstery and plastic components at least once a month with a mild soap and water solution.

▲ **NOTICE: Do not use solvents, abrasive waxes, caustic chemicals or spray silicone to clean the Stand Assist.**

▲ **NOTICE: Do not use abrasive cleansers to clean the Stand Assist; they could scratch the finish.**

▲ **NOTICE: Do not use steam or high pressure cleaners to clean the Stand Assist.**