

How It Works

Air Supply™ generates an intense electrostatic ion wind that charges floating particles in the breathing zone.

The particles are then repelled away from the wearer substantially creating a particle free exclusion zone for toxic allergens, smoke, dust, viruses and bacteria in the breathing zone. Perfumes and odors are also minimized by the Air Supply™ ionization effect.

Significant and substantial reductions of airborne breathable particles have been confirmed by leading world authorities in health related aerosol studies by Wein Air Supply™ technology from .04 to 3 microns in size.

This represents most viruses and bacteria. Because this happens outside the body. It does not matter how infectious or toxic these particles are!

Substantial inhalation risk reductions were confirmed under strict laboratory conditions in confined spaces (aircraft cabin simulations) and large test calibration chambers (rooms) used.

A leading aerosol scientist who peer reviewed the studies said:

"Whether a particle is biological or virulent in humans is of no relevance while it is airborne."

"While still airborne, these virulent particles obey the same laws and effects as all airborne particles of the same aerodynamic size and density."

Testing with inert particles of the same size and density therefore yields a very powerful methodology to characterize any floating particle whether infectious or not!

See www.weinproducts.com for more information.

Disclaimer

These ionic devices are not medical products! Do not reduce or eliminate any approved therapy or drugs prescribed by a physician. These do not treat or cure any disease of the body, but they do reduce the inhalation risk of airborne viruses or bacteria similar to the action of a mask. Neither the Wein

AS150MM Air Supply™ MiniMate nor any surgical mask or respirator mask can offer 100% protection against viral or bacterial infections including sars coronavirus.

Infectious agents can enter the body by other routes including touch, contact, hand/oral food ingestion, etc. Public health authorities recommend frequent and thorough hand washing. Particularly after any contact with suspected sars carriers or patients or any objects including your own mask that may be contaminated with sars coronavirus. Added protection against sars coronavirus or other infectious airborne agents.

Mask/Air Supply combination

Recent testing has confirmed a dramatic enhancement effect for masks of infectious particle exclusion using this combination of mask and Wein wearable Wein AirSupply™ MiniMate AS150MM from .04 to 3 microns.

Further research is being conducted in this area.

Wein Products is the creator of wearable air purification and has been the leading brand with safety and effectiveness certifications by world authorities and University research institutes.

The Good Housekeeping Institute tested the Air Supply in independent controlled multi-person studies. They then had the results reviewed by experts and doctors and recommended the Wein Air Supply on US television on Dateline NBC which you can see on our website: www.weinproducts.com

"IF YOU CAN'T BREATHE, NOTHING ELSE MATTERS!"
(AMERICAN LUNG ASSOCIATION)

The Air Supply® does not treat or cure people of any disease, it does treat the air people breathe to help make it fresher and safer because it substantially reduces the inhalation risk of toxic particles including airborne viruses and bacteria like SARS CORONAVIRUS, INHALATION ANTHRAX and SMALLPOX. It has even been laboratory tested against INFLUENZA sized particles!