


HONEYBULL Walking Cane



FEATURES

- Ergonomic handle
- Pivot base
- Eight adjustable heights, 30 inches to 37 inches
Perfect for people between 5 ft and 6 ft 6 in
- Foldable design for easy storage
- 4 inch no scratch Extra Grip base

VIDEO

Scan the QR code for an instructional video for your Walking Cane.



LIMITATIONS AND SAFETY PRECAUTIONS

WARNING

To reduce risk of injury due to improper or unsafe use of this cane, please read these instructions and safety precautions before use.

- DO NOT disassemble the body of the cane. This can damage the elastic cord inside the cane. Uncontrolled release of the elastic cord could cause SEVERE injuries.
- If the elastic cord is damaged, discontinue use. DO NOT stretch the cord more than is needed to set up or stow away the cane.

LIMITATIONS

- This cane is not intended to absorb the full weight of the user
- This cane is not intended for use by persons over 350 pounds (158 kg)
- This cane is not to be used on icy, slippery, or wet surfaces
- This cane is not intended for use by persons with latex allergies
- This cane is intended to be used as a walking aid




MAINTENANCE

- Check elastic cord before use everytime. DO NOT use the cane if the cord is damaged.
- Periodically check the screws on the feet to be sure they are secure, if not use a screwdriver to tighten the feet.
- Replace the feet every six months.

SAFETY PRECAUTIONS


- Consult a physician before use of any walking aid
- Do not use the walking cane unless the segments and push button are secure and tightened to locked in place
- When straightening the segments, keep your fingers away to avoid being pinched
- Do not stretch the internal elastic cord more than necessary
- Do not use the walking cane if the elastic cord is cut or damaged
- If the handle or bottom base becomes loose, stop use of the walking cane and contact us

SAFETY PRECAUTIONS


<p>Do not over pull the segments and stretch out the elastic cord.</p> 	<p>Be sure the screws are tight on the bottom of the cane. Make sure to replace the foot every 6 months.</p> 	<p>The walking cane is designed to adapt to many environments but make sure to not use your walking cane on surfaces like these:</p>  <p>Uneven floors Throw rugs</p>
---	--	--

SETTING UP YOUR WALKING CANE

Read before use




PUTTING AWAY YOUR WALKING CANE



OPTIMAL USE OF THE WALKING CANE

HEIGHT OF THE WALKING CANE

The walking cane can adjust between 30 to 37 inches tall. The best height to have your walking cane at is your hips.



CONTACT US

Please contact us if you have any trouble at the email below or use the QR code to the right!

SUPPORT@HONEYBULL.COM

