

**ZADRO®**

Z'Fogless Bluetooth Water Mirror  
Model Number: ZW20TSBT

## Important Safety Instructions

READ ALL INSTRUCTIONS BEFORE USE

### OPERATING INSTRUCTIONS

**NOTE:** For a fog-free experience, warm water must be added to water reservoir each time before use.

#### FOG FREE MIRROR USE



1. Slide mirror portion straight up from base.
2. Fill the mirror portion with warm water from your shower.
3. Slide mirror portion back down onto base.
4. Your patented Z'Fogless Mirror is ready for use.

#### TURN THE LIGHTS ON OR OFF

1. To turn lights on, simply press the "Touch Light" button at the base of the mirror.
2. After use, press the "Touch Light" button again to turn off the lights.

#### TURN THE UNIT ON (BLUETOOTH PAIRING)

1. Press and hold the button for 3 seconds until you hear "Power ON Bluetooth Mode". The blue indicator light will flash quickly letting you know your Shower Mirror is now in Bluetooth Pairing Mode.
2. Set Bluetooth enabled device (Phone, Tablet, etc.) to search for Bluetooth devices.
3. Click the device labeled Zadro Fogless BT and listen for the "Pairing Confirmed" prompt. The blue indicator light will stop flashing and remain on letting you know your device is now successfully paired and ready for Bluetooth use.

#### TURN THE UNIT OFF

1. To turn the unit off press and hold the button for 3 seconds until you hear "Power OFF".

#### PLAYING MUSIC

To enjoy wireless music on your Bluetooth Shower Mirror, make sure you are paired with a Bluetooth enabled device. Once paired, you can control the music from the control buttons on your Bluetooth Shower Mirror.

#### PLAYING MUSIC IN BLUETOOTH MODE

##### Play, Pause or Resume Music

- Short Press the button to play, pause or resume music.

##### Next or Previous Songs

- Short Press the button to go to the previous song.
- Short Press the button to go to the next song.

#### SWITCH BETWEEN FM RADIO & BLUETOOTH MODE

Short Press the button to switch between FM Radio & Bluetooth modes. You will hear "FM Radio Mode" or "Bluetooth Mode" that confirms your selection.

#### PLAYING MUSIC IN FM RADIO MODE

**FM Radio Set-Up & Automatic Station Tuning. To select stations automatically:**

1. Long Press the button for 3 seconds until you see the blue indicator light flashing quickly.
2. The system will search through the entire band to find radio stations within reception range. Please be sure to let the scan complete. If you do not end the Seek tuning function, it will end automatically after it has run through the entire waveband once.
3. Your radio stations have now been set-up.

#### Search Radio Stations While in FM Radio Mode

- Once your radio stations have been set-up following the above instructions, Short Press the button to go to the previous frequency. Continue to Short Press the button until the desired station is found.
- Short Press the button to go to the next frequency. Continue to Short Press the button until the desired station is found.

#### ADJUSTING THE VOLUME

- **To Raise the Volume** Long Press the button for 3 seconds and hold until the desired volume is achieved.
- **To Lower the Volume** Long Press the button for 3 seconds and hold until the desired volume is achieved.

#### PHONE OPERATION

Make sure you are paired with a Bluetooth enabled device. Once paired, you can answer or end calls from the control buttons on your Bluetooth Shower Mirror.

#### Redial the Last Number Called or Missed

- Long Press the button on you Bluetooth Shower Mirror. The last number called or missed will be redialed.

#### Answering a Call

- When receiving a call, your Bluetooth Shower Mirror will prompt you with "Connect to Incoming Call".
- To answer a call Short Press the button on you Bluetooth Shower Mirror while your phone is ringing.

#### Rejecting a Call

- When receiving a call, your Bluetooth Shower Mirror will prompt you with "Connect to Incoming Call".
- To reject a call Long Press the button on you Bluetooth Shower Mirror while your phone is ringing.

#### Ending a Call

- To end your call, Short Press the button.

### CARE AND MAINTENANCE

- Use included squeegee to clean mirror.
- For best mirror quality, clean with a soft, non-abrasive cloth. **DO NOT SCRATCH.**
- To avoid water spots and accidentally activating the touch light, position mirror in an area without water over-spray from shower.
- Some showers will leave water spots on mirror surface. This is normal, simply clean the mirror surface with soft cloth.

- Water will drain very slowly from the bottom of the water mirror. Do not obstruct water drainage.

### MOUNTING INSTRUCTIONS - 3 MOUNTING OPTIONS

Select a mounting area in your shower free of overspray and at eye level. Clean the surface before mounting by rinsing and letting dry, then wiping with rubbing alcohol.



**Suction Cups:** Insert suction cups (X3) into the keyholes on the base. Only install on smooth surfaces such as glass or smooth tile. Moistening the inside of the cups will improve adhesion. \*Will not hold on porous surfaces.



**Tape:** Ensure the surface is cleaned with alcohol and allowed to air dry. Press the tape firmly to the mirror base and then to the wall. Silicone may not be necessary with use of tape.



**Silicone:** The silicone adhesive takes 24 hours to cure. Use double stick tape in conjunction with silicone. Apply silicone to the back of the mirror base. The tape will hold the base in position while the silicone cures.

After the mirror base is firmly attached, slide the mirror reservoir onto the base. Regularly check to ensure the mirror is firmly secured.

### BATTERY REPLACEMENT

#### LOW BATTERY

When your batteries are low you will hear "Low Batteries. Please Replace".

#### BATTERY REPLACEMENT

The battery compartment is located on the backside of the Bluetooth Shower Mirror. To replace the batteries, use these instructions:

1. Before attempting to replace batteries, turn Bluetooth Shower Mirror off.
2. Remove the water reservoir portion of the unit to reveal the compartment cover on the base of the unit.
3. Remove the two battery compartment screws.
4. The compartment holds three (3) AA batteries. All three batteries are required and must be properly positioned for the unit to operate.
5. Once the batteries have been inserted, replace the battery compartment cover and screws.
6. Your Bluetooth Shower Mirror is now ready for you to use.

#### CARE/DISPOSAL OF ALKALINE BATTERIES

1. Use only fresh AA batteries.
2. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.
3. The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
4. Depleted batteries are to be removed from the item.
5. Dispose of the old batteries properly, and according to your local regulations.
6. Ensure that batteries are kept out of reach of young children.

### DANGER/WARNING

**To reduce the risk of burns, fire, electric shock, or injury to persons:**

- Be sure the mirror is not in a position where it can reflect sunlight. Reflected light can cause fire.
- Close supervision is necessary when this mirror is used by or near children or disabled persons.
- Use this mirror only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

## 1 Year Limited Warranty

Zadro products include a 1 Year limited warranty from date of purchase against defects in materials and workmanship. This warranty does not include damage to the product as a result of misuse or accident.

Should your product become defective during the warranty period, Zadro Products, Inc.™ will repair or replace (at our sole discretion) your product, at no charge. However, you are responsible for properly packing your product and any applicable shipping charges to Zadro Products, Inc.™ Please contact our Customer Service at 800-468-4348, 714-892-9200 or email [customerservice@zadrolnc.com](mailto:customerservice@zadrolnc.com) on how to obtain an RMA (return authorization number). Please have available and/or include a copy of your receipt, model number (ZW20TSBT) and the issue you are experiencing with your product.

**CUSTOMERS OUTSIDE THE UNITED STATES OF AMERICA, PLEASE CONTACT THE RETAILER OF PURCHASE DIRECTLY TO RESOLVE ANY PRODUCT WARRANTY ISSUES.**

Any product returned for preference is subject to a 20% restocking fee of the product and no shipping charges will be refunded.

Zadro Products, Inc.™ shall not be liable for any incidental or consequential damages arising out of defects in this product, whether or not caused by its negligence.

Some states do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Thank you for your purchase! Please visit us online to leave comments, reviews, & see more exciting new products from [www.Zadrolnc.com](http://www.Zadrolnc.com)  
© Zadro Products, Inc.™

**Zadro®**

*Innovative Ideas That Make Life Easier™*

Huntington Beach, CA

Phone: (714) 892-9200

Fax: (714) 892-7477

E-mail: [Zadrolnc@Zadrolnc.com](mailto:Zadrolnc@Zadrolnc.com)

Website: [www.Zadrolnc.com](http://www.Zadrolnc.com)

**Zadro®**  
*Innovative Ideas That Make Life Easier™*



**ZW20TSBT**

Z'Fogless Bluetooth  
Water Mirror

Important Safety Instructions

